

DENON

プリセットコード一覧表 / List of Preset Codes / Liste von voreingestellten Codes / Liste des codes pré-réglés / Lista dei codici pre-regolati / Lista de Códigos Pre-ajustados / Lijst van vooringestelde codes / Förteckning över förinställda koder / 预选代码一览表 / 预选代码一览表

CDプレーヤーのセットアップコード
SETUP CODES FOR CD PLAYERS
SETUP CODES FÜR CD-PLAYER
CODES DE REGLAGE POUR LECTEURS CD
REGOLAZIONE CODICI PER LETTORE CD
AJUSTAR CÓDIGOS PARA LOS REPRODUCTORES DE CD
INSTELCODES VOOR CD-SPELERS
INSTALLINGSKODER FÖR CD-SPELARE
 選射唱盤播放機設置代碼
 選射唱盤播放機設置代碼

A	
ADC	0004
Acoustic Research	0048
Adcom	0021, 0038
Aiwa	0003, 0018, 0023
Akai	0022
Alba	0058
Alto	0059
Arctics	0023
Ariston	0059
Audio Alchemy	0034
Audio Pro	0051
Audio Research	0023
Audio-Technica	0025
AudioTen	0023
Audiolab	0023
Audiomeca	0023
B	
BSR	0034, 0039
Bestar	0024
Burmester	0048
Bush	0039, 0058
C	
CDC	0048
CEC	0027
California Audio Labs	0006, 0043
Cambridge	0023
Carera	0034
Carver	0023, 0029, 0051
Condor	0024
Craig	0058
Crown	0017
Cyrix	0023
D	
DAK	0039
DBX	0040
DKK	0001
DMX Electronics	0023
Denon	0000

Dual	0034, 0035
Dynamic Bass	0029
E	
EEC	0034
Eclipse	0059
Elektra	0048, 0051
Emerson	0021, 0024, 0044, 0054
F	
Fisher	0014, 0027, 0029, 0045
G	
GE	0002
Garrard	0039, 0041, 0046, 0048, 0049
Gemini	0059
Genesis	0007, 0024, 0044, 0050
GoldStar	0047
Goodmans	0039, 0041, 0044, 0058, 0059
Grundig	0023
H	
HCM	0059
Herman/Kardon	0023, 0026, 0050
Hiro	0059
Hitschi	0007, 0021
I	
IR	0001
Intel	0030, 0035, 0051
J	
JVC	0012, 0061, 0064
K	
Kenwood	0005, 0008, 0009, 0033
Kodak	0042
Krell	0023
Kyocera	0004
L	
LG	0044
Lim	0023
Luxman	0015
M	
MCS	0006, 0010
MFC	0048, 0059
Magnavox	0023, 0044
Marantz	0006, 0023, 0030
Matsui	0023
McIntosh	0042
Memorex	0021, 0024, 0028, 0030, 0044
Meridian	0023
Micromega	0023
Miro	0001
Mission	0023
Mitsubishi	0022
Myriad	0023

N	
NAD	0001
NEC	0010, 0038
NSM	0023
Nagaoka	0004
Naim	0023
Nakamichi	0020
Nikko	0024, 0025, 0027, 0059
O	
Onkyo	0016
Optimus	0001, 0007, 0009, 0013, 0019, 0026, 0029, 0034, 0035, 0041, 0044, 0045, 0048, 0050, 0051, 0053
P	
PMG	0024
Panasonic	0006, 0043, 0065
Parasound	0034, 0048
Philips	0023, 0042
Pink Triangle	0059
Pioneer	0007, 0044, 0053
Porti Audio	0023
Poppy	0024
Proton	0023
Q	
QED	0023
Quad	0023
Quasar	0006
R	
RCA	0002, 0007, 0011, 0021, 0029, 0044, 0053, 0066
Radiotone	0058, 0059
Realistic	0021, 0024, 0028, 0029, 0030, 0048
Revox	0023
Roadstar	0052
Rotel	0023, 0048
Royal	0048
S	
SAE	0023
STS	0004
Sansui	0023, 0036, 0044, 0059
Sanyo	0013, 0029, 0045
Schneider	0058
Scott	0021, 0024, 0044
Seers	0044
Sharp	0009, 0030
Sherwood	0030, 0035, 0050
Shure	0010
Sonic Frontiers	0023
Sony	0001, 0056, 0057
Soundesign	0019, 0049
SuperTech	0059
Synergy	0059
T	
Tandy	0007
Tascam	0048
Teac	0021, 0030, 0046, 0048, 0058, 0059
Technics	0006, 0037, 0043
Thomson	0011
Thorens	0023
U	
Universum	0011, 0023, 0051
V	
Vector Research	0034, 0047
Victor	0012

W	
Wards	0011, 0023
Watson	0058
Y	
Yamaha	0008, 0025, 0032
Yox	0052
Z	
Zenith	0058

ミニディスクのセットアップコード
SETUP CODES FOR MINIDISC (MD)
SETUP CODES FÜR MINIDISCS (MD)
CODES DE REGLAGE POUR MINIDISCS (MD)
REGOLAZIONE CODICI PER MINIDISCO (MD)
AJUSTAR CÓDIGOS PARA MINIDISCOS (MD)
INSTELCODES VOOR MINIDISCS (MD)
INSTALLINGSKODER FÖR MD-SPELARE
 迷你磁碟播放機設置代碼
 迷你磁碟播放機設置代碼

B	
BSR	1000
C	
Condor	1000
D	
Danco	1111
Denver	1003
J	
JVC	1015
K	
Kenwood	1004, 1005, 1012
L	
Luxman	1009
O	
Onkyo	1007
Optimus	1013
Orion	1011
P	
Pioneer	1013, 1017
S	
Schneider	1000
Sharp	1006
Sherwood	1014
Sony	1001, 1002
T	
Technics	1016
U	
Universum	1018
Y	
Yamaha	1008

DBSのセットアップコード
SETUP CODES FOR DIGITAL BROADCAST SATELLITE
SETUP-CODES FÜR DIGITALE SENDESATELLITEN-TUNER
CODES DE REGLAGE POUR TUNER D'ÉMISSION PAR SATELLITE
REGOLAZIONE CODICI PER SINTONIZZATORE VIA SATELLITE PER TRASMISSIONI DIGITALI
AJUSTAR CÓDIGOS PARA SINTONIZADOR DE EMISIONES DIGITALES POR SATELITE
INSELCODES VOOR DIGITALE SATELLITONTVANGER
INSTALLINGSKODER FÖR SATELLITMOTTAGARE
數碼廣播衛星設置代碼
設碼广播卫星設置代碼

A			
ABSat	3549		
ACS	3529, 3531		
ASLF	3533		
Akai	3507		
Akana	3528		
Alba	3516		
Alisat	3507		
Altech	3533		
Alpha	3528		
AlphaStar	3542		
Amstronca	3533		
Amstrad	3550		
Anglo	3533		
Ankara	3533		
Armstrong	3510		
Asat	3507		
Astacom	3528		
Astra	3510, 3521		
Astro	3506		
Athena	3528		
Axiel	3528		
B			
BT	3528, 3531		
Bestar	3510		
Blaupunkt	3506		
Boca	3510		
British Sky Broadcasting	3550		
Broco	3533		
Bubu Sat	3533		
C			
Canal Digital	3551		
Canal Satellite	3551		
Canal+	3551		
Chapanel	3508		
CityCom	3501, 3546		
Columbia	3528		
Columbia	3502		
Columbus	3528		
Condor	3521		
Conrad	3501, 3521		
Crown	3510		
Cybus	3507		
D			
D-box	3536		
DNT	3507		
Daewoo	3533		
Discovery	3531, 3528		
Dynasat	3529		
E			
EP Sat	3516		
EchoStar	3505, 3513, 3518, 3533, 3543, 3551, 3556, 3560, 3569		
Einhell	3510, 3533		
Ela	3507		
Emme Esse	3529, 3556		
Engel	3533		
F			
FTE	3554		
Fennher	3528		
Ferguson	3532		
Finlandia	3516		
Finlux	3516		
Foxtel	3558		
Fracarro	3556		
Fuba	3506		
G			
GE	3519		
Galaxis	3512, 3554		
Gardiner	3546		
General Instrument	3555		
Gold Box	3551		
Gooding	3520		
Goodmans	3518		
Gradiente	3559		
Granada	3516		
Grundig	3506, 3520, 3540, 3550		
H			
HTS	3543		
Helium	3521		
Hirschmann	3506, 3568		
Hitachi	3516, 3547		
Houston	3528		
Hughes Network Systems	3539, 3574, 3575		
Humax	3554		
Huth	3510		
I			
IR	3506, 3516		
iSkyB	3559		
InVideo	3556		
Indovision	3569		
Intertronc	3510		
Intervision	3521, 3524		
J			
JOK	3531		
JVC	3520, 3543		
K			
K-SAT	3533		
Kathrein	3506, 3507, 3523, 3527		
Kreiselmeyer	3506		
L			
La Sat	3521		
Lenco	3533		
Lifesat	3533		
Loewe	3510		
Lorenzen	3521, 3538		
M			
Magnavox	3535, 3537		
Manana	3531		
Manhattan	3516		
Marantz	3507		
Maspro	3540		
Matsui	3520		
Max	3521		
MediaSat	3551		
Mediamarkt	3510		
Medion	3533		
Mega	3507		
Memorex	3537		
Metronic	3510		
Metz	3506		
Micro	3530		
Micro Electronic	3533		
Microtec	3533		
Minerva	3520		
Mitsubishi	3539		
Morgan's	3502, 3510		
Multichoice	3526, 3558		
Myyvad	3507		
Mysat	3530		
N			
Netsat	3559		
Neuhaus	3530		
Neusat	3530		
Next Level	3555		
Nikko	3533		
Nokia	3516, 3536, 3541, 3557, 3563, 3573		
Nordmende	3516		
O			
Okano	3510, 3528		
Orbit	3562		
Oxford	3528		
P			
Pace	3509, 3516, 3517, 3534, 3545, 3550, 3569		
Palladium	3520		
Panasat	3522, 3558		
Panasonic	3511, 3530, 3550		
Panda	3516		
Patriot	3528		
Philips	3503, 3507, 3516, 3520, 3531, 3535, 3537, 3539, 3540, 3551, 3567, 3574		
Pioneer	3514, 3551		
Prima	3545		
Profile	3531		
Promax	3516		
Prosat	3524		
Proscan	3515		
Pye	3520		
Q			
Quadral	3524		
Quelle	3521		
R			
RCA	3504, 3515, 3519, 3552		
RFT	3507		
Radio Shack	3555		
Radiala	3507		
Roadstar	3533		
Rover	3524, 3533		
S			
SEG	3538		
SKR	3533		
SKY	3553, 3559		
SM Electronic	3533		
Saba	3531		
Sabre	3516		
S			
Sagem	3548, 3572		
Samsung	3571		
Sat Team	3533		
Satec	3533		
Satline	3524		
Schneider	3528		
Seemann	3510		
Seleco	3556		
Siemens	3536		
Skatlin	3533		
Sky Television	3561		
SkyMaster	3524, 3533		
Skymax	3507		
Smart	3503		
Sony	3525, 3550		
Snar	3559		
Snar Choice	3555		
Strong	3502, 3558		
Sumsda	3510		
Sunsat	3533		
Sunstar	3510		
Super Sat	3529		
T			
TPS	3548		
Tartec	3516		
Tatung	3516		
Technisat	3570		
Technowelt	3521		
Teco	3510		
Teleska	3510		
Telestar	3500		
Telexes	3516		
Televisa	3559		
Thomson	3516, 3532, 3551, 3566		
Thom	3516		
Tonna	3528		
Toshiba	3539, 3544		
Trax	3501		
U			
Uندن	3535, 3537		
Unisat	3507, 3510		
Universum	3506, 3520		
V			
Vision	3546		
Variocast	3506		
Ventana	3507		
Vestel	3538		
W			
Wela	3533		
Wewa	3516		
Wisi	3506, 3516		
World Sat	3531		
X			
XSat	3528		
Xoom Multimedia	3528		
Z			
Zehnder	3500, 3546		
Zenith	3553		
Zeta Technology	3507		
Zwergnase	3510		

Minata	3531		
Manhattan	3516		
Marantz	3507		
Maspro	3540		
Matsui	3520		
Max	3521		
MediaSat	3551		
Mediamarkt	3510		
Medion	3533		
Mega	3507		
Memorex	3537		
Metronic	3510		
Metz	3506		
Micro	3530		
Micro Electronic	3533		
Microtec	3533		
Minerva	3520		
Mitsubishi	3539		
Morgan's	3502, 3510		
Multichoice	3526, 3558		
Myyvad	3507		
Mysat	3530		
N			
Netsat	3559		
Neuhaus	3530		
Neusat	3530		
Next Level	3555		
Nikko	3533		
Nokia	3516, 3536, 3541, 3557, 3563, 3573		
Nordmende	3516		
O			
Okano	3510, 3528		
Orbit	3562		
Oxford	3528		
P			
Pace	3509, 3516, 3517, 3534, 3545, 3550, 3569		
Palladium	3520		
Panasat	3522, 3558		
Panasonic	3511, 3530, 3550		
Panda	3516		
Patriot	3528		
Philips	3503, 3507, 3516, 3520, 3531, 3535, 3537, 3539, 3540, 3551, 3567, 3574		
Pioneer	3514, 3551		
Prima	3545		
Profile	3531		
Promax	3516		
Prosat	3524		
Proscan	3515		
Pye	3520		
Q			
Quadral	3524		
Quelle	3521		
R			
RCA	3504, 3515, 3519, 3552		
RFT	3507		
Radio Shack	3555		
Radiala	3507		
Roadstar	3533		
Rover	3524, 3533		
S			
SEG	3538		
SKR	3533		
SKY	3553, 3559		
SM Electronic	3533		
Saba	3531		
Sabre	3516		

Sagem	3548, 3572		
Samsung	3571		
Sat Team	3533		
Satec	3533		
Satline	3524		
Schneider	3528		
Seemann	3510		
Seleco	3556		
Siemens	3536		
Skatlin	3533		
Sky Television	3561		
SkyMaster	3524, 3533		
Skymax	3507		
Smart	3503		
Sony	3525, 3550		
Snar	3559		
Snar Choice	3555		
Strong	3502, 3558		
Sumsda	3510		
Sunsat	3533		
Sunstar	3510		
Super Sat	3529		
T			
TPS	3548		
Tartec	3516		
Tatung	3516		
Technisat	3570		
Technowelt	3521		
Teco	3510		
Teleska	3510		
Telestar	3500		
Telexes	3516		
Televisa	3559		
Thomson	3516, 3532, 3551, 3566		
Thom	3516		
Tonna	3528		
Toshiba	3539, 3544		
Trax	3501		
U			
Uندن	3535, 3537		
Unisat	3507, 3510		
Universum	3506, 3520		
V			
Vision	3546		
Variocast	3506		
Ventana	3507		
Vestel	3538		
W			
Wela	3533		
Wewa	3516		
Wisi	3506, 3516		
World Sat	3531		
X			
XSat	3528		
Xoom Multimedia	3528		
Z			
Zehnder	3500, 3546		
Zenith	3553		
Zeta Technology	3507		
Zwergnase	3510		

VCRのセットアップコード
 SETUP CODES FOR VCR
 SETUP-CODES FÜR VIDEOGERÄTE
 CODES DE REGLAGE POUR MAGNETOSCOPE
 REGOLAZIONE CODICI PER VIDEOREGISTRATORE (VCR)
 AJUSTAR CÓDIGOS PARA VCR
 INSTALCODES VOOR VIDEORECORDER
 INSTALLINGSKODER FOR VIDEOBANDSPELARE
 録画機設置コード
 录像机设置代码

A

ASA 3006, 3018
 AVP 3034
 Adelsound 3022
 Admiral 3014, 3026
 Adventura 3000
 Adyson 3017
 Aiko 3030
 Anwa 3000, 3006, 3033, 3034
 Aka 3029, 3030, 3031
 Akiba 3017
 Akura 3017
 Alba 3017, 3026, 3030, 3031, 3034
 Allstar 3018
 America Action 3030
 American High 3005
 Amstrad 3000, 3030
 Anam 3006, 3023, 3028, 3029, 3030
 Anam National 3023, 3028, 3036, 3050
 Amitech 3017
 Ansonic 3002
 Anstona 3018
 Asha 3029
 Asuka 3006
 Audiosonic 3030
 Audiovox 3006

B

Baird 3000, 3009, 3019
 Basic Line 3017, 3030
 Beumark 3029
 Bell & Howell 3019
 Bestar 3030
 Blutpunkt 3023, 3025, 3028
 Blue Sky 3030
 Bondstec 3017
 Brandt 3022
 Brandt Electronic 3009
 Broksonic 3001, 3021, 3024, 3026, 3033, 3037
 Bush 3017, 3026, 3030, 3034

C

CCE 3017, 3030
 CGE 3000
 Calix 3005
 Canon 3009
 Canera 3026
 Canefour 3012
 Carver 3018
 Cathay 3030
 Canning 3017
 Ceneral 3030
 Citizen 3006, 3030
 Colt 3017
 Combitech 3034
 Condor 3030
 Craig 3006, 3013, 3017, 3029
 Crown 3017, 3030
 Curtis Mathes 3005, 3009, 3015, 3023, 3044

Cybernet 3029
 Cybus 3018

D

Daleco 3012, 3030, 3043
 Darsai 3017
 De Graaf 3010
 Decco 3000, 3018
 Demco 3010
 Diamant 3006
 Domland 3026
 Dual 3009
 Dumont 3000, 3018, 3019
 Dynatech 3000

E

ESC 3029, 3030
 Eibe 3007
 Elatech 3017
 Electrohome 3006
 Electrophonic 3006
 Elex 3029
 Elsay 3017
 Eta 3017, 3030
 Emerex 3003
 Emerson 3000, 3001, 3006, 3011, 3021, 3024, 3026, 3030, 3037

F

Ferguson 3009, 3032
 Fidelity 3000
 Finlandia 3018, 3019
 Finlux 3000, 3010, 3018, 3019
 Firstline 3006, 3011, 3012, 3017, 3026
 Fisher 3013, 3019
 Flint 3026
 Fuji 3004, 3005
 Fujitsu 3000
 Funai 3000

G

GE 3005, 3014, 3015, 3029, 3044
 GEC 3018
 Galaxis 3030
 Garrard 3000
 General Technic 3033
 Genesco 3019
 Go Video 3036
 GoldHand 3017
 GoldStar 3006, 3007, 3027
 Goodmans 3000, 3006, 3017, 3030
 Graduate 3000
 Graetz 3009, 3019, 3029
 Granada 3018, 3019
 Grandin 3000, 3006, 3017
 Grundig 3017, 3018, 3025, 3028

H

HCM 3017
 Hi-Q 3013
 Hansmex 3034
 Hansonic 3006
 Harley Davidson 3000
 Harman/Kardon 3007, 3018
 Harwood 3017
 Hiatt 3002, 3017, 3029, 3034
 Hisawa 3034
 Hischiro 3012
 Hitachi 3000, 3002, 3009, 3010, 3029
 Homophone 3018
 Hughes Network Systems 3010
 Hypon 3017

I

IR 3002, 3009, 3010, 3012, 3013, 3017, 3018, 3019, 3020, 3026, 3028, 3029, 3033
 ITT 3000, 3019, 3020, 3029
 IVO 3006, 3030
 Imperjet 3000
 Ingersoll 3002
 Inno Hit 3017, 3029
 Interfunk 3018
 Intervision 3000, 3005, 3026, 3030
 Iradio 3017, 3018

J

JVC 3008, 3016
 Jensen 3009

K

KEC 3006, 3030
 KLH 3017
 Kaisu 3017
 Kando 3020, 3026
 Karswood 3007, 3009, 3018
 Kimai 3013
 Kneissel 3034
 Kodak 3005, 3006
 Korpel 3017
 Kuba Electronic 3013
 Kyoto 3017

L

LXI 3006
 Lenco 3030
 Leyco 3017
 Lloyd's 3000
 Loewie 3002, 3006, 3018, 3023, 3036, 3050
 Logik 3002, 3017, 3029
 Luxor 3011, 3014, 3018, 3020

M

M Electronic 3000, 3007
 MEI 3028
 MGA 3011, 3029
 MGN Technology 3029
 MTC 3000, 3029
 Magnasonic 3030
 Magnavox 3000, 3005, 3008, 3018, 3022, 3038
 Magnin 3029
 Manesath 3012, 3017
 Marantz 3005, 3018
 Marzi 3006
 Matsui 3002, 3026, 3033, 3034
 Matsushita 3005, 3023, 3036
 Medion 3033
 Memorex 3000, 3005, 3006, 3008, 3013, 3014, 3019, 3023, 3026, 3029, 3033, 3036, 3037, 3046, 3050, 3052
 Memphis 3017
 Metz 3006, 3023, 3025, 3036, 3050
 Minerva 3025
 Minolta 3010
 Mitsubishi 3011, 3014, 3016, 3018
 Motorola 3005, 3014
 Multitech 3000, 3017
 Murphy 3000
 Myriad 3018

N

NAD 3019
 NAP 3008
 NEC 3007, 3009, 3016, 3019
 National 3028

Nackermann 3018
 Nesco 3017
 Nikai 3017, 3030
 Nikko 3006
 Noblex 3029
 Nokia 3009, 3019, 3020, 3029
 Nordmende 3009, 3032

O

Oceanic 3000, 3033
 Okano 3031, 3033
 Olympus 3005, 3028
 Optimus 3006, 3014, 3019, 3023, 3035, 3036, 3047, 3048, 3050, 3052
 Orion 3001, 3002, 3021, 3024, 3026, 3033, 3034, 3037
 Osaki 3000, 3006, 3017
 Otake 3026
 Otto Versand 3018

P

Palladium 3006, 3009, 3017
 Panasonic 3005, 3023, 3027, 3028, 3036, 3040, 3048, 3050, 3052, 3053
 Pathe Cinema 3002, 3011
 Pathe Marconi 3009
 Penray 3025, 3006, 3007, 3010, 3029
 Pentax 3010
 Perdio 3000
 Philco 3005, 3007, 3026, 3037
 Philips 3005, 3018, 3038, 3041, 3049, 3051
 Phonola 3018
 Pilot 3006
 Pioneer 3016, 3018
 Polk Audio 3018
 Portland 3030
 Pro Vision 3030
 Profronic 3029
 Proline 3000
 Proscan 3015, 3044
 Prosonic 3030
 Prospec 3017
 Pulsar 3008
 Pye 3018

Q

Quasar 3005, 3023, 3036, 3050
 Quelle 3018

R

RCA 3005, 3010, 3014, 3015, 3020, 3022, 3029, 3044
 RFT 3017
 Radialva 3006, 3014
 Radio Shack 3000, 3046
 Radionia 3018
 Radix 3006
 Randex 3006
 Realistic 3000, 3005, 3006, 3013, 3014, 3019
 ReplayTV 3039, 3040
 Rex 3006
 Roadstar 3006, 3017, 3029, 3030
 Rumco 3008

S

SBR 3018
 SEG 3029
 SEI 3062, 3018
 SES 3010
 Saba 3009, 3032
 Saisho 3002, 3026
 Salora 3011, 3020
 Samsung 3012, 3029, 3035

Sanyo	3008, 3014
Sansui	3000, 3009, 3016, 3026, 3037
Sarwa	3002
Sanyo	3013, 3019, 3029
Saville	3034
Schaub Lorenz	3000, 3009, 3019
Schneider	3000, 3017, 3018
Scott	3011, 3012, 3021, 3024
Sears	3000, 3005, 3006, 3010, 3013, 3019
Seleco	3009
Semp	3012
Senra	3017
Sharp	3014
Shronts	3017, 3019
Shwartz	3006
Shogun	3029
Shora	3002
Siemens	3006, 3018, 3019, 3025
Siera	3018
Siva	3006
Singer	3012, 3017
Sinudyne	3002, 3018
Sonnecor	3017
Sortec	3008
Sony	3000, 3003, 3004, 3005, 3042, 3045
Soundwave	3006, 3026
Ssangyong	3017
Stem	3030
Sunkal	3033
Sunstar	3000
Suntronic	3000
Sunwood	3017
Supra	3006
Sylvania	3000, 3005, 3011, 3018
Symphonic	3000

T	
TMK	3029
Taksho	3002, 3026
Tandberg	3030
Tandy	3000, 3019
Tashiko	3000
Tatung	3000, 3009, 3018
Teac	3000, 3009, 3030, 3043
Tec	3017, 3030
Tech Line	3017
Technics	3005, 3023, 3028
Teleska	3000, 3005, 3006
Televia	3009
Telefunken	3009, 3032
Teletch	3017
Tenosai	3017
Tensar	3000
Thomas	3000
Thomson	3009, 3015, 3016, 3032
Thorn	3009, 3019
Tivo	3041, 3042
Tokai	3017
Toshiba	3009, 3011, 3012, 3018
Totevision	3006, 3029

U	
Uher	3029
Ultravox	3030
Unitach	3029
Universum	3000, 3006, 3018, 3020, 3025, 3029

V	
Vector	3012
Vector Research	3007
Victor	3009, 3016
Video Concepts	3012
Videasonic	3029
W	
Weards	3000, 3005, 3010, 3013, 3014, 3015, 3017, 3018, 3022, 3029, 3044
Watson	3018
White Westinghouse	3017, 3026, 3030
X	
XR-1000	3000, 3005, 3017
Y	
Yamaha	3007
Yamaha	3017
Yokan	3017
Yoko	3029
Z	
Zenith	3000, 3004, 3008, 3026, 3037

CDRのセットアップコード
 SETUP CODES FOR CDR
 SETUP-CODES FÜR CDR
 CODES DE REGLAGE POUR CDR
 REGOLAZIONE CODICI PER CDR
 AJUSTAR CÓDIGOS PARA CDR
 INSTELCODES VOOR CDR
 INSTALLINGSKODER FOR CDR
 設置 CDR 代碼
 設置 CDR 代碼

D	
Danon	0000, 0001
H	
HFB	0500
K	
Kenwood	0501
M	
Marantz	0501
N	
NAD	0503
P	
Philips	0501
Pioneer	0500, 0502
R	
RCA	0502

ケーブルのセットアップコード
 SETUP CODES FOR CABLE
 SETUP-CODES FÜR KABEL
 CODES DE REGLAGE POUR CABLE
 REGOLAZIONE CODICI PER CAVI
 AJUSTAR CÓDIGOS PARA CABLE
 INSTELCODES VOOR KABEL
 INSTALLINGSKODER FOR KABEL-TV-MOTTAGARE
 纜線設置代碼
 纜線設置代碼

A	
ABC	4001, 4002, 4005, 4006
Alcatel	4028, 4029
American	4030
B	
Bell & Howell	4005
Bell South	4030
Birmingham Cable Communications	4012
British Telecom	4001
C	
Cable & Wireless	4034
Cabletime	4018, 4024
D	
Daeonyung	4002
F	
Filmnet	4017
France Telecom	4019, 4028, 4029
G	
Galaxi	4002
General Instrument	4020, 4025
GoldStar	4008
H	
Harris	4003, 4011
J	
Jerrold	4001, 4004, 4005, 4012, 4020, 4025
M	
MNiet	4017
Macab	4026
Memorex	4050
Motorola	4020, 4035
Mr. Zap	4036
N	
Neos	4026
O	
Ono	4034
P	
PVP Stereo Visual Matrix	4001
Pace	4009, 4032, 4034
Panasonic	4000, 4007
Paragon	4009
Philips	4015, 4016
Pioneer	4008, 4023, 4027, 4037
Pulsar	4000
Q	
Quasar	4000
R	
Regal	4011, 4014
Runco	4000
S	
Sagem	4026
Samsung	4008

Scientific Atlanta	4002, 4006, 4013, 4021, 4027,
	4037
Sony	4031
Starcom	4001
Supercable	4012
T	
Tele+1	4017
Tocom	4004
Toshiba	4000
U	
United Cable	4001
V	
Videoway	4010
Visionics	4033
Visiopath	4019
Z	
Zenith	4000, 4022, 4030

テレビのセットアップコード
 SETUP CODES FOR TELEVISION
 SETUP-CODES FÜR FERNSEHGERÄTE
 CODES DE REGLAGE POUR TELEVISION
 REGOLAZIONE CODICI PER TELEVISION
 AJUSTAR CODIGOS PARA TELEVISION
 INSTALINKODES VOOR TELEVISIE
 INSTALLINGSKODER FOR TV-APPARATER
 電線機置置代碼
 电视机設置代碼

A	
A-Mark	4501
A.R. Systems	4593
ADC	4501, 4508, 4512, 4518, 4554
AWA	4502
Acura	4502
Admiral	4531, 4545, 4585
Advantus	4516
Adyson	4564
Aiko	4530
Aiwa	4612
Aki	4502, 4512, 4562, 4565, 4596
Akb	4572
Akiba	4514, 4565, 4571, 4572, 4584
Akura	4565, 4569
Alaron	4552, 4563
Alba	4502, 4513, 4514, 4565, 4579, 4607
Allogan	4572
Altair	4514
Ambassador	4550
America Action	4553
Amplison	4564
Ampro	4619
Amstrad	4502, 4514, 4549, 4550, 4579, 4581
Anam	4501, 4502, 4553, 4568
Anam National	4522, 4508, 4605
Anglo	4569
Antech	4502
Ansonic	4502, 4514, 4578
Arcam	4563, 4564
Archer	4501
Arcton	4514, 4593
Asora	4502
Asuka	4565
Atlantic	4561
AudioTon	4564, 4569
Audiovision	4514, 4536
Autovox	4501, 4530, 4553, 4583, 4599
Autovox	4581

B	
BPL	4571
BSP	4572
BTC	4565
Baird	4571, 4527, 4557, 4558, 4562, 4564
Basic Line	4502, 4565
Baur	4514, 4590, 4592
Baysonic	4553
Bazo	4564
Beaumarck	4551
Beko	4578, 4615
Belcor	4508
Bell & Howell	4525, 4542
Beon	4514
Best	4578
Bestar	4514, 4578, 4580

Binatone	4564
Blaupunkt	4500, 4573, 4574
Blue Sky	4505, 4607
Blue Star	4571
Boots	4564
Bradford	4563
Brandt	4536, 4575
Brinkmann	4512, 4582
Britanna	4563
Brookwood	4508
Broksonic	4501, 4567, 4585
Bush	4502, 4513, 4514, 4505, 4571, 4572, 4576, 4579, 4590, 4607

C	
CCE	4514, 4564
CGE	4576, 4582
CX Electronics	4563
CIS	4553
Candle	4512, 4516, 4523, 4555
Canon	4565
Canad	4598
Carera	4514, 4584
Carnival	4512
Carrefour	4513
Carver	4521, 4548
Casadio	4502
Cathay	4514
Celebrity	4500
Centurion	4514
Cemline	4502
Cenral	4530, 4583
Citizen	4512, 4515, 4516, 4523, 4524, 4530, 4555, 4570
City	4502
Clartone	4564
Clartox	4514
Clatron	4578
Concerto	4523
Condor	4578
Conic	4502, 4513, 4553, 4554, 4563
Continental Edison	4536, 4588
Cosmal	4514
Craig	4553
Crosley	4521
Crown	4502, 4514, 4515, 4553, 4578, 4582
Curtis Mathes	4565, 4512, 4515, 4517, 4518, 4521, 4523, 4524, 4531, 4539, 4542, 4547, 4583, 4586, 4618, 4622, 4626
Cyberton	4565

D	
DCR	4557, 4558
Deerwo	4502, 4508, 4514, 4515, 4530, 4542, 4580, 4583, 4599, 4600
Demichi	4565
Dansai	4514
Dayton	4502
Daytron	4508
De Graaf	4562
Decca	4514, 4526
Denko	4569
Denon	4539
Denval	4514
Desmat	4502, 4514
Diamond	4514
Diex	4502, 4514
Dual	4514, 4564
Dual Tec	4564
Durumont	4506, 4506, 4525
Dwin	4617, 4620

E	
ECE	4514
Elbe	4564
Electroband	4500, 4554
Electa	4569
Elco	4514
Elco	4565
Elta	4502
Emerson	4508, 4515, 4542, 4550, 4551, 4552, 4553, 4554, 4567, 4570, 4571, 4585, 4599, 4600
Emperor	4571
Envision	4512
Eres	4504, 4514
Elron	4502
Euromart	4514, 4569
Europa	4514
Euphonia	4564
Expert	4561
Exquisit	4514

F	
Falmer	4502, 4580
Ferguson	4514, 4527, 4536, 4557, 4568, 4575
Fidelity	4558, 4563
Filips	4564
Finlandia	4562
Firlux	4514, 4525, 4526, 4552
Firstline	4502, 4563, 4564, 4572, 4607
Fisher	4542, 4544, 4562, 4564, 4578
Flint	4584
Forrestone	4558
Formanti	4514
Fortress	4531
Frabe	4514, 4578
Friac	4502, 4578
Frontech	4545, 4569
Fujitsu	4524, 4552, 4561, 4609
Funai	4549, 4552, 4553, 4568, 4572
Futuretech	4553

G	
GBC	4502, 4565, 4680
GE	4510, 4511, 4517, 4518, 4522, 4531, 4538, 4551, 4571, 4583, 4618, 4622, 4626
GEK	4514, 4526, 4564
GPM	4565
Galax	4514
Galexi	4514, 4578
Galopso	4502
General	4555
General Technic	4502
Genexco	4545, 4565
Gibraltar	4506, 4508, 4512
GoldStar	4506, 4512, 4514, 4515, 4523, 4536, 4551, 4564
Gooding	4588
Goodmans	4513, 4514, 4526, 4552, 4564, 4579, 4580, 4600
Gorenje	4578
Gradiente	4520, 4523, 4548
Graetz	4545
Granada	4514, 4526, 4562, 4564
Grandin	4571, 4598
Grundig	4595, 4514, 4525, 4560, 4588, 4593, 4595
Grumpy	4552, 4553

H	
HCM	4502, 4571, 4581
Halfax	4564
Hallmark	4551
Hampton	4563, 4564
Hanimax	4572
Hansatic	451, 4593
Hantarex	4514
Hantoro	4514
Harley Davidson	4552
Hartman/Kardon	4521
Harvard	4553
Harwood	4502, 4514, 4581
Hera	4502, 4564
Hikona	4565
Hinat	4502, 4513, 4514, 4552, 4565
Hisava	4571, 4584
Htachi	4506, 4513, 4523, 4536, 4539, 4541, 4545, 4564, 4594
Hornophone	4514
Huanyu	4553, 4580
Hyper	4502, 4553, 4564
Hyson	4514, 4569, 4571

I	
ICE	4564, 4569, 4579
ICeS	4565
IR	4503, 4504, 4513, 4514, 4525, 4526, 4527, 4531, 4534, 4535, 4546, 4545, 4557, 4588, 4595
Infinity	4560, 4561, 4563, 4564, 4566, 4572, 4573, 4578, 4580, 4590, 4592, 4593
ITS	4579
ITT	4545
ITV	4514, 4569
Iberia	4514
Imperial	4578, 4582
Indiana	4514
Infinity	4571
Ingenel	4545
Ingersol	4502
Inno Hit	4526
Intera	4514
Intex	4506
Interbuy	4514, 4569
Interfunk	4514, 4545, 4592
Internal	4514
Intervision	4514, 4564, 4569
Intecho	4565, 4579
Iruka	4565

J	
JB	4521
JVC	4500
JCB	4513, 4520, 4532, 4557, 4579, 4586
Janeil	4506
K	
KB Aristocrat	4545
KEC	4553
KTV	4512, 4515, 4553, 4554, 4564, 4570
Kaisai	4502, 4563, 4564, 4565, 4571
Kamp	4563
Kapsch	4545, 4561
Karcher	4598
Kesu	4571
Kathrein	4593
Kawashio	4563
Kaypani	4519
Kendo	4514

Kennedy4561
 Kerwood4508, 4512
 Kingsley4563
 Kloss4516
 Kressall4514, 4590, 4598
 Kolster4514
 Korika4602, 4603, 4604, 4613, 4614
 Korpel4514
 Kosmos4514
 Koyoda4502
 Kyohsu4581
 Kyoto4545
L
 LG4523
 LXI4517, 4521, 4542, 4543, 4551, 4618
 Leyco4514, 4526, 4569, 4572
 Liesenk & Tier4514
 Liesenkötter4514, 4573
 Lifetec4514, 4505, 4580
 Loewie4592
 Logic4505
 Luma4561
 Lumatron4564
 Luxman4523
 Luxor4599
M
 M Electronic4502, 4514, 4536, 4545, 4564, 4580, 4587
 MEI4554
 MGA4508, 4512, 4540, 4551
 MTC4508, 4512, 4523, 4524, 4554, 4563, 4592
 Magnafon4527, 4563
 Magnavox4509, 4512, 4513, 4521, 4533, 4552, 4555, 4566, 4624
 Magnum4514
 Majestic4505
 Manearth4564, 4569
 Marantz4512, 4514, 4521, 4593
 Merk4514
 Metsui4502, 4503, 4513, 4514, 4526, 4590, 4592, 4564, 4572, 4576, 4578, 4588
 Matsushita4568, 4605
 Mediator4504, 4514
 Medion4607
 Megs4598
 Megatron4501, 4509, 4651
 Memorex4502, 4526, 4523, 4540, 4542, 4551, 4552, 4568, 4585
 Metz4577
 Midland4506, 4515, 4517, 4518, 4538, 4618
 Minerva4526, 4588
 Minota4581
 Minutzi4510
 Mitsubishi4508, 4513, 4531, 4535, 4540, 4551, 4592
 Mivar4563
 Monaco4502
 Motorola4522, 4531
 Multibroadcast4558
 Multitech4502, 4553, 4563, 4564
 Murphy4515, 4526, 4545, 4563
 Myriad4593

N
 NAD4543, 4547, 4551
 NEC4508, 4512, 4513, 4523, 4548, 4584, 4589
 NEI4514
 NTC4502
 Nakamura4514, 4580
 Nako4587
 National4566
 Neckermann4514, 4590, 4593
 Nessco4552
 Netsat4514
 Neufunk4514, 4593
 New Tech4564
 Nicamagic4563
 Nikas4514, 4526, 4563, 4565, 4569
 Nikko4512, 4530, 4551
 Nobiko4525, 4563
 Nokia4587
 Nordmende4526
 Noshi4567
 Novak4564
 Nowestonic4514
O
 Oceanic4545
 Okano4502, 4514, 4569, 4578
 Omega4569
 Oriva4553
 Optimus4542, 4547, 4568, 4605
 Optronica4531, 4546
 Orion4514, 4590, 4592, 4567, 4572, 4576, 4585
 Orline4514, 4525
 Osaki4526, 4564, 4565, 4569, 4581
 Oslo4514
 Oso4565
 Osume4526
 Otto Versand4513, 4514, 4564, 4590, 4592, 4593
P
 Paal4563
 Palladium4578, 4582
 Panama4564, 4569
 Panasonic4518, 4522, 4537, 4545, 4566, 4569, 4577, 4605
 Panavision4514
 Pathe Cinema4543
 Pausa4502
 Penny4501, 4507, 4508, 4510, 4511, 4512, 4515, 4517, 4518, 4523, 4524, 4538, 4543, 4551, 4618, 4626
 Perdio4514, 4545
 Phico4508, 4509, 4512, 4521, 4533, 4539, 4585
 Philips4504, 4514, 4521, 4558, 4580, 4593
 Phoenix4563
 Phonola4504, 4514
 Pilot4508, 4512, 4515
 Pioneer4536, 4545, 4547, 4608
 Plantron4502
 Playsonic4564
 Portland4508, 4515, 4530
 Precision4564
 Prima4569
 Princeton4616
 Prinz4569
 Prism4518
 Profex4502

Profi4502
 Profifonic4514
 Proline4526
 Proscan4517, 4618
 Prosonic4514
 Protech4502, 4514, 4564, 4569, 4582, 4607
 Proton4501, 4519, 4551, 4586
 Pular4506, 4508
 Pye4504
Q
 Quasar4518, 4522, 4546, 4568, 4605
 Queile4503, 4514, 4525, 4573, 4574, 4590, 4592
 Questa4513
R
 R-Line4514
 RBM4525
 RCA4507, 4508, 4517, 4518, 4529, 4531, 4538, 4608, 4618, 4621, 4622, 4623, 4626, 4627
RIT
 Radialva4514, 4569
 Radio Shack4508, 4512, 4515, 4517, 4523, 4542, 4546, 4551, 4553, 4618
 Radiola4504, 4514
 Radiomarelli4514
 Radstone4502, 4514, 4569
 Rank Awa4513
 Realistic4508, 4512, 4515, 4523, 4542, 4546, 4551, 4553
Recor4514
 Redstar4514
 Reflex4514
 Revox4514
 Rex4545, 4561, 4569
 Rhapsody4554, 4563
 Roadstar4502, 4565, 4569, 4582
 Royal Lux4581
 Runco4506, 4512, 4588, 4597
S
 SBR4504, 4514, 4558
 SEG4513, 4564, 4569, 4607
 SEI4590, 4572
 SEI-Sinudyne4514
 SKY4514
 SSS4508, 4553
 Seba4536, 4545, 4575
 Sagem4598
 Sasho4502, 4503, 4590, 4569
 Salsara4545, 4559
 Sampo4512, 4515, 4519
 Samsung4502, 4508, 4512, 4514, 4515, 4523, 4524, 4529, 4551, 4564, 4569, 4578, 4593, 4595
 Samslux4515
 Sandra4563
 Sansui4583
 Sansui4585
 Sanyo4503, 4513, 4526, 4542, 4544, 4562
 Schneider4514, 4565, 4579, 4607
 Scimitru4508
 Scotch4551
 Scotland4545
 Scott4508, 4551, 4552, 4553, 4567
 Sears4517, 4521, 4523, 4542, 4543, 4544, 4549, 4551, 4552, 4618
 Seleco4545, 4561
 Semivox4553

Semp4543
 Sencora4502
 Sentra4565
 Serno4598, 4563, 4584
 Sharp4513, 4515, 4531, 4546, 4610, 4611
 Shiratschi4514
 Shogun4508
 Shorai4572
 Siemens4514, 4560, 4573, 4574
 Signature4505
 Silva4563
 Silver4513
 Simpson4555, 4556
 Sinudyne4550, 4572
 Sky-Worth4514
 Solavox4545
 Sonotron4562
 Sonoko4502, 4514
 Sontolor4545, 4562
 Sontec4514
 Sony4500, 4503, 4513, 4528, 4590, 4605
Sound & Vision4580
 Soundesign4551, 4552, 4553, 4555
 Soundware4514, 4562
 Spectronic4501
 Squareview4549
 Sangyong4502
 Standard4502, 4564, 4565
 Starline4553
 Sternway4566, 4571
 Stern4545, 4561
 Strato4514, 4569
 Stylandia4564
 Surkal4572, 4576
 Sunstar4502, 4514, 4579
 Sunwood4514
 SuperTech4563
 Supra4523
 Super-Macy4516
 Supreme4500
 Susumu4565
 Sylvania4509, 4512, 4521, 4533
 Symphonic4549, 4553
 Sysline4514
 Syston4563
T
 TMK4523, 4550, 4551
 TNCI4506
 TVTEXT 964593
 Tandberg4577
 Tandy4515, 4526, 4531, 4545, 4564, 4565
 Tashiko4513, 4564
 Teonung4501, 4514, 4522, 4526, 4564
 Teac4502, 4514, 4569, 4571, 4581, 4582, 4584, 4607
 Tec4564
 Tec4518, 4568, 4605
 Technic Ace4552
 Techwood4501, 4518, 4523
 Teknika4506, 4508, 4515, 4521, 4523, 4524, 4530, 4540, 4552, 4553, 4555
 Telefunken4523, 4534, 4536, 4575, 4601
 Telegati4514
 Telemester4514
 Teleonic4514
 Telestar4514
 Teletech4502

Teleton	4513, 4555, 4561, 4564
Television	4563
Temco	4572
Tennessee	4514
Tensai	4505, 4572
Text	4563, 4565
Thomson	4536, 4601, 4627
Thorn	4514, 4526, 4557, 4558, 4590,
	4592
Tokai	4502, 4514, 4545
Tomashi	4571
Toshiba	4513, 4524, 4525, 4542, 4543,
	4591, 4625
Tosonic	4554
Totevision	4515
Trans Continens	4564
Triстар	4598, 4565
Triumph	4550
Tsoschi	4571
U	
Uher	4561
Ultravision	4514, 4563
Unic Line	4514
United	4514
Universal	4511
Universum	4514, 4569, 4578
Univox	4514, 4545
V	
Vector Research	4512
Westel	4514
Victor	4513, 4520, 4568, 4605
Videologic	4565, 4563
Videotechnic	4564
Vidikron	4521
Vitchech	4508, 4513, 4551
Viking	4516
Vision	4564
Vistar	4561
Voxson	4545
W	
Waltham	4564
Wards	4505, 4508, 4509, 4510, 4511,
	4512, 4521, 4523, 4528, 4533,
	4546, 4551, 4552
Watson	4514
Watt Radio	4563
Wega	4513
Wegavox	4502
White Westinghouse	4514, 4563, 4585, 4599, 4600
Windstar	4571
X	
Xrypton	4514
Y	
Yamaha	4508, 4512
Yamishi	4564, 4571, 4584
Yokan	4514
Yoko	4514, 4564, 4569
Z	
Zanussi	4561
Zenith	4505, 4506, 4530, 4585, 4600
Zonda	4501

レーザーディスクのセットアップコード
SETUP CODES FOR LASER DISC
SETUP-CODES FÜR LASER-DISCS
CODES DE REGLAGE POUR DISQUE LASER
REGOLAZIONE CODICI PER DISCHI LASER
AJUSTAR CÓDIGOS PARA DISCOS LASER
INSTELCODES VOOR LASERDISC
INSTALLINGSKODER FOR LASER DISC-SPELARE
設置映像碟播放機設置代碼
設置映像碟播放機設置代碼

A	
Awva	2507
C	
Carver	2502, 2505, 2510
Clyus	2511
D	
Denon	1111, 1112, 1113
Disco Vision	2500
F	
Funai	2507
G	
GoldStar	2503
H	
Harman/Kardon	2505
Hitachi	2500
M	
Magnavox	2505, 2509
Marantz	2502, 2505
Mitsubishi	2501
N	
NAD	2501
O	
Optimus	2501
P	
Panasonic	2508
Philips	2502, 2505, 2511
Pioneer	2500, 2501
Poli Audio	2505
Quasar	2508
R	
Radiola	2511
Realistic	2507
Renaissance	2510
S	
Sakora	2502
Samsung	2510
Sega	2500
Sony	2504, 2506
T	
Technics	2508
Telefunken	2501
Theta Digital	2505
Y	
Yamaha	2509

DVDのセットアップコード
SETUP CODES FOR DVD
SETUP-CODES FÜR DVD
CODES DE REGLAGE POUR DVD
REGOLAZIONE CODICI PER DVD
AJUSTAR CÓDIGOS PARA DVD
INSTELCODES VOOR DVD
INSTALLINGSKODER FOR DVD
設置映像碟播放機設置代碼
設置映像碟播放機設置代碼

A	
Atreedy	2039
Awva	2022
Akai	2018
Apex	2028, 2049
B	
Bush	2035
D	
Denon	0000, 0001
E	
Emerson	2014
F	
Fisher	2027
G	
GE Video	2003
Go Video	2044
Gradiente	2023
H	
Harman/Kardon	2013, 2041
Hitachi	2012, 2025
Hiteker	2028
J	
JMB	2037
JVC	2010, 2017
K	
Kenwood	2000, 2006, 2032, 2048
Konka	2043, 2045, 2046, 2047
L	
LG	2014
Lescon	2038
M	
Magnavox	2001, 2030
Marantz	2007
Microsoft	2003
Mitsubishi	2002
N	
NAD	2036
O	
Onkyo	2001, 2016, 2018
Optimus	2011
Oritron	2023
P	
Panasonic	2000, 2020, 2031
Philco	2035
Philips	2001, 2007
Pioneer	2004, 2011, 2020
Princeton	2029
Praline	2024
Proscan	2003

R	
RCA	2003, 2011, 2042
REC	2034
Realmagic	2029
Roadstar	2034
S	
SM Electronic	2035
Sampo	2039
Samsung	2012
Sanyo	2027
Sharp	2019
Sherwood	2021
Sony	2005
T	
Teac	2011
Technics	2000
Techwood	2036
Theta Digital	2011
Thomson	2003, 2009
Toshiba	2001
U	
Universum	2014
W	
Wesder	2040
Wharfedale	2033, 2038
Y	
Yamaha	2000, 2008
Yamakawa	2026
Z	
Zenith	2001, 2014

カセットプレーヤーのセットアップコード
 SETUP CODES FOR CASSETTE PLAYERS
 SETUP-CODES FÜR CASSETTEN-PLAYER
 CODES DE REGLAGE POUR LECTEURS DE CASSETTE
 REGOLAZIONE CODICI PER RIPRODUTTORE A CASSETTE
 AJUSTAR CODIGOS PARA REPRODUCORES DE CASSETTE
 INSTELCODES VOOR CASSETTEPELERS
 INSTALLINGSKODER FOR KASSETTBANDSPELERE
 卡式錄音帶設置代碼
 卡式錄音帶設置代碼

A	
Alva	1502, 1516, 1517
Alcaj	1525, 1529
Arcam	1506
C	
Carver	1502
D	
Denon	0000
F	
Fisher	1505
G	
Garrard	1527, 1529
Grundig	1502
H	
Harman/Kardon	1502, 1514
I	
Inkel	1503, 1504, 1528
J	
JVC	1521, 1522, 1523
K	
Kerwood	1503, 1504
M	
Magnavox	1502
Marrantz	1500, 1502
Memorex	1509, 1510
Mitsubishi	1521, 1529
Myriad	1502
O	
Onkyo	1511, 1512, 1524
Optimus	1501, 1518, 1528, 1529
P	
Panasonic	1519
Philips	1502
Phonotrend	1528
Pioneer	1501, 1509, 1510, 1518
Polk Audio	1502
R	
RCA	1501, 1518
Revax	1502, 1515
S	
Sansui	1502, 1502
Sanyo	1505
Sherwood	1528
Sony	1513, 1520, 1526
T	
Tae Kwang	1529
Teac	1525, 1527
Technics	1519
Thorens	1502
V	
Victor	1521, 1522, 1523

W	
Wands	1501
Y	
Yamaha	1507, 1508